



HP38



8030ES



8210E



HP18

HP18S



63329A



8050E



8070E



9020E




SC392



8020E



SC630



8170

8171

HP38 My Tutor Smart Learning Board
Teaches words, letters, numbers, & music. Has sound & musical instrument effects Quiz mode. Includes 3 "AA" batteries. box size: 14.75"Lx2"Wx10.25"H. Case pack: 24 pcs 50 lbs/5.10 cu-ft.

8030ES Bilingual Laptop
English/Spanish laptop has 6 learning activities: review letters, numbers, objects, shapes, counting, & spelling on big LCD screen. Music & sound effects guide learning. Includes 3 "AA" batteries. box size: 14"Lx3.25"Wx13.5"H. 6 pcs/inner. Case pack: 12 pcs 50 lbs/5.00 cu-ft.

8210E My First PC Tutor (English)
Flip-open laptop w/ LCD screen. lots of educational activities. requires 3 "AA" batteries. box size: 13.25"Lx3.50"Wx12.25"H. Case pack: 12 pcs 50 lbs/4.80 cu-ft.

HP18 Hello Teacher (English)
HP18S Hello Teacher (Spanish)
13.25" play & learn educational board. includes alphabetic & numeric keys. includes 3 "AA" batteries. box size: 13.25"Lx2.5"Wx9.75"H. Case pack: 24 pcs 48 lbs/5.54 cu-ft.

63329A ABC Tutor
10.5" learning board w/ activity button selection & voice teaching 26 letters & words. Also comes w/ piano keyboard & 8 tunes. Includes 2 "AA" batteries. box size: 10"Lx2"Wx13"H. Case pack: 24 pcs 30 lbs/3.80 cu-ft.

8050E My Phonics Laptop (English)
12"x11" laptop w/ large LCD display. Learning activities teaches letters, words, numbers, spelling, math, quiz games, & music. Includes 3 "AA" batteries. box size: 15.75"Lx14"Wx3"H. 6 pcs/inner. Case pack: 12 pcs 55 lbs/5.40 cu-ft.

8070E Laptop Junior
8.5" purple hippo laptop w/ light up screen, melodies, & 6 buttons to introduce simple letters, numbers, & shapes. Includes 2 "AA" batteries. Age 1 yr. & up. box size: 11.5"Lx9.75"Hx3"W. 12 pcs/inner. Case pack: 24 pcs 44 lbs/5.20 cu-ft.

9020E Talking Alphabet Book (English)
17" fold out electronic learning book. introduce the alphabet, words, objects, numbers, shapes, time, & sound recognition and more. Includes 3 "AA" batteries. box size: 19.5"Lx2.5"Wx14.25"H. Case pack: 6 pcs 26 lbs/2.78 cu-ft.

SC392 My First Sound Book
Touch n' turn sound book has 32 fun sounds effects & voices, teaching animals, vehicles & musical instruments. 36 harmony melodies. Includes 2 "AA" batteries. box size: 13"Lx2.5"Wx11"H. Case pack: 18 pcs 35 lbs/4.00 cu-ft.

8020E Smart PC Explorer (English)
10.25"x9.5" flip-open computer w/ large LCD screen & pull-out directional mouse. Teaches spelling, questions & answers, math quizzes, musical songs. Includes 3 "AA" batteries. box size: 13.5"Lx12.5"Wx3.75"H. 6 pcs/inner. Case pack: 12 pcs 47 lbs/5.40 cu-ft.

SC630 Learning & Activity Laptop
10" laptop w/ LCD screen. 4 games to teach letters & objects. Includes 4 "AA" batteries. box size: 13"Lx3"Wx11.5"H. Case pack: 12 pcs 33 lbs/3.62 cu-ft.

8170 Fun Learning Desk (English)
8171 Fun Learning Desk (Spanish)
Learning desk w/ 5 fun activities introduces letters, numbers, objects, shapes, & spelling on large LCD screen. Includes 3 "AA" batteries. box size: 18"Lx4"Wx15.5"H. Case pack: 6 pcs 28 lbs/4.20 cu-ft.