



06245P



06245T



9058



3018/12



7013



553



32350



32350K



3283



7722



8030B



9682

06245P Metro Force Racing Set
Set includes signs, tracks, two 3.75" speed racers, 2 extra bodies, speed controllers, bridge sections, struts, & more. Requires 4 "W" batteries. box size: 25.75"Lx2"Wx17"H. Case pack: 6 pcs 23 lbs/3.04 cu-ft.

06245T Metro Truck Racing Set
Set includes signs, tracks, two 3.75" pick-up trucks, 2 extra bodies, speed controllers, bridge sections, struts, & more. Requires 4 "W" batteries. box size: 25.75"Lx2"Wx17"H. Case pack: 6 pcs 23 lbs/3.00 cu-ft.

9058 Speedy Flyer Road Racing Set
Set includes racers w/ headlights & magnetic base, car bodies, 8.2" length track, signs, speed controllers, & flyover struts. 4 "D" batteries not included. box size: 26.75"Lx17.5"Hx1.75"W. Case pack: 9 pcs 23 lbs/2.98 cu-ft.

3018/12 Super Bike Racing Set
Bike racing set includes bikes, tracks, & struts. Layout size: 79"x44". Requires 3 "AA" batteries. box size: 26"Lx5.5"Wx19"H. Case pack: 3 pcs 32 lbs/5.44 cu-ft.

7013 Union Express Train
Train set w/ 111" track. Chugs, lights, & smokes. Requires 2 "W" batteries. box size: 19.5"Lx2.75"Wx11.5"H. Case pack 12 pcs 25 lbs/4.90 cu-ft.

553 Union Express
8 pc track layout of 2.7M of track w/ smoking loco, working headlight, & chug-chug sound. Requires 2 "D" batteries. box size: 14.75"Lx2.75"Wx10.5"H. Case pack: 36 pcs 61 lbs/9.60 cu-ft.

32350 Western Train
50 pc set includes tracks, headlights, & sound station w/ sound effects. 5 cars (locomotive, oil tanker, coal tender, carriage, caboose). 2 "AA" batteries not included. box size: 22.25"Lx2"Wx14.5"H. 6 sets/inner. Case pack: 12 pcs 35 lbs/5.60 cu-ft.

32350K Santa's Train
50 pc set includes tracks, headlights, & sound station w/ Xmas songs. 5 festive cars (locomotive, oil tanker, coal tender, carriage, caboose). 2 "AA" batteries not included. box size: 22.25"Lx2"Wx14.5"H. 6 sets/inner. Case pack: 12 pcs 35 lbs/5.60 cu-ft.

3283 Santa Fe Express
34 piece train set w/ 140" track 3 train sounds. Includes 2 "AA" for sound. Requires 2 "W" batteries for train motion. box size: 26"Lx3.5"Wx16.5"H. Case pack: 6 pcs 26 lbs/5.00 cu-ft.

7722 Southern Railway
Railcars (locomotive, tender, gondola, caboose) on 7 pc track. Includes bridge, cable stand, tunnel, trees, & 4 figures. Requires 1 "AA" battery. box size: 12.25"Lx1.5"Wx10.5"H. Case pack: 36 sets 28 lbs/5.32 cu-ft.

8030B Loco Max
14"x11.5" board allows train to make stops & run along tracks. Requires 1 "C" battery. box size: 16.5"Lx2"Wx12.25"H. Case pack: 12 pcs 31 lbs/3.60 cu-ft.

9682 Royal Express Train
Train set includes cars & cabooses, tracks, castle, & 2 figurines. 2 "AA" batteries not included. box size: 23.5"Lx2.5"Wx14"H. Case pack: 12 pcs 30 lbs/6.30 cu-ft.